

VP Series

High-Speed Vibrating Mixer



The VP series can mix the ink that is in the container: it can mix the ink tank as it is.

It's only 3 steps. Putting the ink tank into the mixer, fixing the tank, and adjusting time and speed.

Inks is vibrated quickly within the container for a few minutes causing a vortex convection from top to bottom of the container blending the ink uniformly.

The entire process is conducted inside the container.* Therefore, mixing blades and mixing tools are not required and free from odor and powder dust.

*Soft container cannot be applied to the machine.
Please do not use deformed tank.

VPA-02 Variable speed type

VP-01 Fixed speed type

VPA-10 Max mixing capacity 10kg variable speed type



YOSHIKAWA CHEMICAL CO., LTD.

6-27, 1-CHOME, KYUTARO-MACHI, CHUO-KU, OSAKA 541-0056, JAPAN

TEL : 06-6266-2251

2-10-4, KANDA OGAWA-MACHI, CHIYODA-KU, TOKYO 101-0052, JAPAN

TEL : 03-3294-5051

E-mail : info@yoshikawa-chemical.co.jp

Speedy

When stirring at high speed for 3 to 7 minutes with VP series, the ink is completed uniformly.



Putting the ink you want to mix in a container



Clamp the container to the VP series.



After mixing three minutes, above mixture is uniform.

Please check our Youtube channel !!



<https://www.youtube.com/watch?v=fgLCwZkT3Lc&t=2s>

Easy and High performance



The panel designed for easy use

High viscosity inks can be mixed for a few minute as well as low viscosity inks. With The VP series, powder and liquid can also be mixed together* so that this machine can be adopted for various businesses.

*Inks, silver paste, powder, cosmetics (foundation), and so on.

Specification

We deal with various models such as the model with stirring speed fixed and high performance model capable of stirring 10 kg containers.

Model	Dimensions (mm)	Power/Air supply	Speed	Clamping type	Max container size (mm)	Mixing cap.
VP-01	380(D)×430(W)×965(H)	AC110V 6A 400w 50/60Hz	fixed	rock lever type	240(D)×240(W)×246(H)	MAX 5kg
VP-02		AC110V 6A 400w	variable			
VPA-01	380(D)×430(W)×965(H)	AC110V 6A 400w 50/60Hz 0.4~0.6MPa	fixed	air clamp type	240(D)×240(W)×226(H)	
VPA-02		AC110V 6A 400w 0.4~0.6MPa	variable			
VPA-10	520(D)×630(W)×1250(H)	AC100V 10A 750w 0.4~0.6MPa	variable	air clamp type	325(D)×325(W)×310(H)	MAX 10kg

The Air compressor is sold separately. The design and specifications are subject to change without prior notice.



<振動式攪拌機 VP シリーズ VIBRATION MIXER>

<https://www.youtube.com/watch?v=fgLCwZkT3Lc>

Youtube 吉川化工

検索



<吉川化工 Facebook>

<https://www.facebook.com/yoshikawachemical>

Facebook 吉川化工

検索

